


S

A pplications in Breweries



The Brewing Process



The basic steps of the brewing process are:


- Malt milling
- Wort production
- Fermentation, maturation and yeast propagation
- Filtration, carbonization and bright beer storage

Breweries require auxiliary process steps as water treatment, cooling and CIP systems, pneumatic systems but also CO₂ accommodation

Physical values to be measured:

- Flow
- Pressure
- Temperature
- Level

Applications in the brew house



Limit switch:

Sitran CLS, LVS, LPS, LVL

Level:

- Hydrostatic:

Sitran P300, DSIII, P310

- Radar:

Sitran LR260 and LR460

Ultrasonic:

**Sitran LU01/02/10
with sensors XPS 30/40**

Flow:

**Sitran FM MAG 1100F,
Sitran FM MAG3100
Sitran FC**

Pressure:

Sitran P300, P310

Temperature:

**Pt100 with Sitran TS500
or Sitran TR**


Positioner:

Sitran PS2

Weighing:

Siwarex

Applications in fermentation



Limit switch:

[Sitrans CLS](#), LVL

Level:

- Hydrostatic:

[Sitrans P300](#), [DSIII](#)

- Radar:

[Sitrans LR200](#) and [LR300](#)

Flow:

[Sitrans FM MAG 1100F](#)

[Sitrans FC](#)

Pressure:

[Sitrans P300](#)

Temperature:

[Pt100](#) with [Sitrans TH](#)
or [Sitrans TR](#)


Positioner:

[Sitrans PS2](#)

Weighing:

[Siwarex](#)

Applications in maturation and filtration



Limit switch:

[Sitrans CLS](#), LVL

Level:

- Hydrostatic:

[Sitrans P300](#), [DSIII](#)

- Radar:

[Sitrans LR200](#) and [LR300](#)

Flow:

[Sitrans FM MAG 1100F](#)

[Sitrans FC](#)

Pressure:

[Sitrans P300](#)

Temperature:

[Pt100](#) with [Sitrans TH](#)
or [Sitrans TR](#)

Positioner:

[Sitrans PS2](#)

Level measurement



Hydrostatic level measurement

Digital transducer with front flush membrane

Low drift and high precision

High Turn Down Ratio (1:100)

IP 68

EHEDG approval



Continuous level measurement at grain or malt silos increases production flexibility

SITRANS LU

A compact and easy to install device for up to ten measurements with one transmitter for silos up to 20 m. High performance at an reasonable price.

SITRANS LR 260/460

24 GHz radar devices for continuous measurement for silo heights up to 30, resp. 100 m for high performance requirements in solids.

Flow measurement



MAGFLO MAG1100 Food

Magnetic – inductive flow meter with SENSORPROM and flexible communication (HART, PROFIBUS DP & PA, MODBUS, DeviceNet)

- ✓ Liners
(ceramics (Al₂O₃) or PFA)
- ✓ Accuracy
(0,25 % of actual flow value)
- ✓ Measuring uncertainty
(+/- 0,5 % actual flow value)
- ✓ Approvals
(3A, EHEDG for ceramics)



MASSFLO MASS 2100

High performance Mass Flow Meter (Coriolis) with SENSORPROM Technology and flexible communication (HART, PROFIBUS DP & PA, MODBUS, DeviceNet)

- ✓ Range
(0 – 52.000 kg/h)
- ✓ Accuracy
(0,1 % of actual flow)
- ✓ Added value
(measuring of density and temperature)

Weighing technology

Malt weighing hopper




Solid flow meter



Continuous dosage of 50 kg malt at a daily capacity of 200 t with full integration in the SIMATIC S7 and PCS 7

- ✓ Metering deviation of complete system < 10 g
- ✓ Batch error < 20 g
- ✓ 450 batches per hour
- ✓ Direct integration in S7 or PCS 7

"Solid Flowmeasurement" based on SIEWREX weighing technology using an existing deflector system



Temperature measurement & positioner



Resistance thermometer

with 1x or 2x Pt100 class A, 3-wire for installation in pipes and tanks or non insertion type clamp-on thermometer



Positioner

- Electro pneumatic positioner SIPART PS2 for control valves, for linear and part turn actuators
- Time efficient automatic commissioning functionality, diagnostic functionality for valves and actuators
- Split installation for extreme ambient conditions
- Cost saving by minimized air consumption



Case Study Plato Measurement

Metering in the Brewhouse SITRANS F C MASSFLO mass flow meter

Introduction to in-line Plato measurement

In the brewhouse, wort concentration is traditionally controlled by measuring gravity, at a well-defined temperature, with a hydrometer.

Several measurements are taken during the boiling process. Prior to fermentation, a final water adjustment to the wort concentration may be necessary.

There is uncertainty associated with this manual method of measurement due to evaporation and each brewer's way of performing the measurement. Furthermore, brewing capacity is wasted in boiling to a concentration higher than the target value with a subsequent water adjustment.

Lautering can be optimized when an in-line Plato meter is included in the lauter tun run-off to control sparging. The sparging process can be stopped when the wort concentration has dropped to a level where transfer to the wort kettle is no longer desirable. An in-line Plato meter can also identify channelling which causes the yield of the lauter tun to drop.


Continuous monitoring is possible with the addition of an in-line Plato meter in a closed loop on the wort kettle. The boiling process can be stopped at the exact target value, resulting in higher brewing capacity and better quality of the end product.

In-line measurement vs manual measurement

$$\text{Plato} = \frac{\sum_{i=1}^n \rho_i}{\sum_{i=1}^n K_{m_i}} \cdot T^{\frac{1}{n}}$$


SITRANS F C MASSFLO internal Plato calculation

- SITRANS F C MASSFLO measures the density and temperature of the wort.
- To each pair of density and temperature values corresponds an exact wort concentration. This relationship has been developed in an algorithm, which is programmed into SITRANS F C MASSFLO.
- The Plato algorithm enables SITRANS F C MASSFLO to measure the wort concentration at the actual process temperature. No cooling prior to measurement is necessary.



Installation for monitoring the wort kettle
SITRANS F C MASSFLO should be placed in a closed loop on the wort kettle. The same pump used for whirlpooling can be used to force circulation.

Digital communication, or a 4 - 20 mA signal, can be used to connect SITRANS F C MASSFLO to the control and monitoring system. This enables automatic heat transfer adjustments to the wort kettle and, when the target concentration has been reached, automatic cessation of heating.



Installation for monitoring sparge water
SITRANS F C MASSFLO should be placed in the run-off of the lauter tun.

Digital communication, or a 4 - 20 mA signal, can be used to connect SITRANS F C MASSFLO to the control and monitoring system. This enables automatic stopping of sparging when the target concentration drops to the minimum level.



Total Extract calculation

Total extract can be easily calculated in the control system. Real-time Plato and mass flow measurements are multiplied and then integrated in the control system to measure total extract. This can be used at any location in the brewhouse to track yield and identify process problems.

food &
BEVERAGE

In-line, temperature-independent Plato meters, connected directly to the brewer's process computer, allows control what will optimize the brewing process.

SIEMENS

SITRANS F C MASSFLO Specifications

Meter size	1/2"	1"	1 1/2"	2"	
Connections Tri-Clamp	1"	1-1/2"	2"	2", 3"	
Flow accuracy ¹⁾	0.1%	0.1%	0.1%	0.1%	of rate
Flow repeatability ¹⁾	0.05%	0.05%	0.05%	0.05%	of rate
Density accuracy ¹⁾	0.0005	0.0005	0.0005	0.0005	g/cc
Density repeatability ¹⁾	0.0001	0.0001	0.0001	0.0001	g/cc
*Plato accuracy ¹⁾	0.1	0.1	0.1	0.1	°Plato
*Plato repeatability ¹⁾	0.05	0.05	0.05	0.05	°Plato

¹⁾ Typical accuracy and repeatability is 2 - 3 times better than stated.


Siemens Flow Instruments AS
DK-6450 Nordborg
Denmark

Order No.
SIFOR.PA.02B.N1.UK

Siemens AG
Subject to change without prior notice

Case Study Flow measurement

Siemens flowmeters save money and improve filtration in Brazilian brewery plants SITRANS FM MAGFLO flowmeter



Using SITRANS FM MAGFLO flowmeter for dosing additives, a number of brewery production facilities have taken leave of human errors in a vital process.

SIEMENS

The challenge

"We were in the hands of operators", this is how Américo Bernardino, vice-president, describes the situation until recently as regards the dosing of additives in a range of the South American brewery giant's production facilities throughout Brazil.

The additives concerned are used in the filtration process for quality reasons, and they are:

- Ascorbic acid solution for anti-oxidation. The additive enables Ambev to guarantee six months shelf life of the beer.
- Foam stabilizer, added to protect the foam from flat after the beer has left the packaging. In this case the quality aspect is merely visual, yet vital to the product image.

Until November 2000 these critical functions were controlled manually with piston pumps, adjusted by operators via a micrometer. The result was checked in a laboratory, and at the mercy of human imperfection errors would occur.

"Sometimes the liquids were not added, at other times they were added when there was no beer in the tank. This could force us to repeat the filtration process or mix the contents of a tank with other batches", Mr. Florido explains.

The solution

To overcome these drawbacks it was decided to install Siemens MAGFLO flowmeters to control the dosing of the two additives. Installation was carried out in the second largest plant of the group in Jacareí, close to São Paulo, in November 2000, followed by another eight similar plants and one in Paraguay soon after.

Due to the automation, dosing of additives is now controlled according to the varying beer flow. The results have been most satisfying, not least thanks to substantial savings on the consumption of additives. The antioxidant makes up a good example.

The benefit

Before the introduction of flow control, the consumption of antioxidant solution was 4.8 g/hl. Today the consumption has been reduced to 3.5 g/hl (27 percent less). At an annual output of approx. 9 million hectolitres the 1.3 g/hl reduction saves 11,700 kilos of antioxidant solution. At a price of 7 USD per kilo the total yearly savings are 85,100 USD – in the Jacareí plant alone.

In addition to this tangible benefit, a range of improvements regarding quality and operation was obtained. Mr. João Luis, maintenance manager in Jacareí, tells:

"Earlier we frequently had to deal with varying quality in the tanks. Now we obtain a highly homogeneous product. Moreover, monitoring of the pumps, performed by the flowmeters, has reduced maintenance to a matter of changing the pump hoses every 4-6 months. That has done a lot of good to downtime", he notes and sums up the benefits of the automated filtration as follows:

- Money saved
- The human factor reduced
- Homogeneity and thus quality improved
- Maintenance decreased



Part of the filtration plant with MAGFLO sensors installed, measuring antecedent and foam stabilizer.